

## How LeRobot Hackathon Winners Built AI-Robots With NVIDIA Isaac GR00T



NVIDIA Omniverse  
49K subscribers

Subscribe

👍 145



🔗 Share

💡 Ask

🔖 Save



4,426 views Streamed live on Jul 31, 2025

Join us for a special livestream featuring two winning teams from the LeRobot Worldwide Hackathon: Spice Terminator and LeDetective DaVinci. See how these teams used GR00T N1.5 and the SO-101 robot to build AI-powered systems that understand natural language and perform complex real-world tasks. From robotic cleaning driven by vision-language-action models to AI agents solving mysteries like a detective, this session is full of innovation, creativity, and real-world applications of physical AI.

# Vision Language Action Models for Lerobot

## Who are we?



**Sanan Garayev**  
MS in Robotics and AI @UCL  
Former AI Engineer @Baykar  
Technologies



**Ton Hoang (Bill) Nguyen**  
Contributor @Google Deepmind  
Software & AI Engineer  
@Hammer Missions



**Pulkit Gera**  
Applied Scientist Intern  
@Flawless



**Atharva Deshmukh**  
Research Engineer  
@Epic Games



**William W. Whatley**  
Fractional CTO / CPO @Catalyst  
Technologies

## What did we do?




🏆 Novelty Price in the local  
**Embodied AI Hackathon** organized  
by  
**Society for Technological  
Advancement (SoTA)** in London


🏆 28th place out of 250 submissions  
in the **Global Lerobot Hackathon**  
organized by **HuggingFace**

We achieved these with our **Spice  
Terminator** 🤖 and Web UI.

## Spice Terminator



## Web User Interface




## Overview


1. Introduction to Vision Language Action (VLA) Models
2. SO101 Arm and LeRobot configurations
3. Experiment setup and dataset collection process
4. Model fine-tuning workflow
5. Running inference on the real robot

## Vision Language Action (VLA) Models

Models that combine visual understanding, natural language processing, and action generation to control physical agents (robots) from high-level instructions.




# GR00T N1 Model Architecture



NVIDIA et al. (2025). GR00T N1: An open foundation model for generalist humanoid robots.

# SmoIVLA Model Architecture



Shukor, M., et al. (2025). SmoIVLA: A vision-language-action model for affordable and efficient robotics.

## VLA Model Comparison

Feature	SmoVLA	GR00T N1.5
Goal	Lightweight, fast	High-capacity, generalist
Model Size	Small (edge-friendly) 450M	Medium/Large 3B
Use Case	Simple table-top tasks	Complex household tasks

## LLM Model Training

01	Pre-training phase	02	Fine-tuning	03	Reinforcement Learning from Human Feedback
<ul style="list-style-type: none"><li>- Learning how to predict next tokens</li><li>- Uses large-scale internet data</li><li>- Model is trained for so long time</li><li>- Regardless of cleaning, the datasets involve too much noise</li></ul>		<ul style="list-style-type: none"><li>- Specializing the model to specific tasks (e.g., question-answering in ChatGPT)</li><li>- Clearly collected less noisy data</li><li>- Few-shot ability for further fine tuning</li></ul>		<ul style="list-style-type: none"><li>- Reducing the risk of hallucinations</li><li>- Human feedback collection</li><li>- Further model training on the collected human feedback</li></ul>	

## VLA Model Training

01	Pre-training phase	02	Fine-tuning
<ul style="list-style-type: none"><li>- Learning how to predict action tokens</li><li>- Uses large-scale internet video data</li><li>- Uses large-scale cross-embodiment data</li><li>- Model is trained for so long time</li><li>- Regardless of cleaning, the datasets involve too much noise</li></ul>		<ul style="list-style-type: none"><li>- Specializing the model to specific tasks (e.g., cleaning kitchen, cutting apples, putting fruit to bags)</li><li>- Clearly collected less noisy data</li><li>- Simulation benchmark datasets to improve the success rates</li></ul>	

## Section 2: SO101 Arm and Lerobot Environment Configuration



# SO101 Arm Configuration



- |    |                                  |
|----|----------------------------------|
| 01 | Physical setup                   |
| 02 | Motor setup                      |
| 03 | Arm joint calibration            |
| 04 | Camera setup (dual camera setup) |
| 05 | Full teleoperation with camera   |

**Hugging Face** Search models, datasets, users...

Models Datasets Spaces Community Docs Pricing Log In Sign Up

**LeRobot**

Search documentation

MAIN EN 16,246

**POLICIES**

Finetune SmolVLA

**ROBOTS**

Hope Jr

**SO-101**

SO-100

Koch v1.1

LeKiwi

**RESOURCES**

Notebooks

**ABOUT**

Contribute to LeRobot

**Join the Hugging Face community**  
and get access to the augmented documentation experience

Collaborate on models, datasets and Spaces

Faster examples with accelerated inference

Switch between documentation themes

Sign Up to get started

**SO-101**

In the steps below, we explain how to assemble our flagship robot, the SO-101.

**Source the parts**

Follow this [README](#). It contains the bill of materials, with a link to source the parts, as well as the instructions to 3D print the parts. And advise if it's your first time printing or if you don't own a 3D printer.

**SO-101**

Source the parts

Install LeRobot

Step-by-Step Assembly Instructions

Clean Parts

Joint 1

Joint 2

Joint 3

Joint 4

Joint 5

Gripper / Handle

Configure the motors

1. Find the USB ports associated with each arm

2. Set the motors ids and baudrates

Setup motors video

LeRobot

Search documentation Ctrl+K

MAIN EN 16,246

www.huggingface.co/docs/lerobot

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

SO-101

SO-100

Koch v1.1

LeKiwi

RESOURCES

Notebooks

ABOUT

Contribute to LeRobot

Backward compatibility

pip install -e ".[feetech]"

Step-by-Step Assembly Instructions

The follower arm uses 6x STS3215 motors with 1/345 gearing. The leader, however, uses three differently geared motors to make sure it can both sustain its own weight and it can be moved without requiring much force. Which motor is needed for which joint is shown in the table below.

Leader-Arm Axis	Motor	Gear Ratio
Base / Shoulder Pan	1	1 / 191
Shoulder Lift	2	1 / 345
Elbow Flex	3	1 / 191
Wrist Flex	4	1 / 147
Wrist Roll	5	1 / 147
Gripper	6	1 / 147

Clean Parts

Remove all support material from the 3D-printed parts. The easiest way to do this is using a small screwdriver to

SO-101

Source the parts

Install LeRobot

Step-by-Step Assembly Instructions

Clean Parts

Joint 1

Joint 2

Joint 3

Joint 4

Joint 5

Gripper / Handle

Configure the motors

1. Find the USB ports associated with each arm

2. Set the motors ids and baudrates

Setup motors video

Follower

Leader

LeRobot

Search documentation Ctrl+K

MAIN EN 16,246

www.huggingface.co/docs/lerobot

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

SO-101

SO-100

Koch v1.1

LeKiwi

RESOURCES

Notebooks

ABOUT

Contribute to LeRobot

Backward compatibility

0:00 / 0:19

Joint 4

- Slide over motor holder 4.
- Slide in motor 4.
- Fasten motor 4 with 4 M2x6mm screws and attach its motor horns, use a M3x6mm horn screw.

0:00 / 0:12

SO-101

Source the parts

Install LeRobot

Step-by-Step Assembly Instructions

Clean Parts

Joint 1

Joint 2

Joint 3

Joint 4

Joint 5

Gripper / Handle

Configure the motors

1. Find the USB ports associated with each arm

2. Set the motors ids and baudrates

Setup motors video

Follower

Leader

LeRobot

Search documentation Ctrl+K

MAIN EN 16,246

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

SO-101

SO-100

Koch v1.1

LeKiwi

RESOURCES

Notebooks

ABOUT

Contribute to LeRobot

Backward compatibility

0:00 / 0:27

Configure the motors

1. Find the USB ports associated with each arm

To find the port for each bus servo adapter, connect MotorBus to your computer via USB and power. Run the following script and disconnect the MotorBus when prompted:

```
python -m lerobot.find_port
```

Mac Linux

Example output:

```
Finding all available ports for the MotorBus.
['/dev/tty.usbmodem575E0032081', '/dev/tty.usbmodem575E0031751']
Remove the USB cable from your MotorsBus and press Enter when done.

[...Disconnect corresponding leader or follower arm and press Enter...]
```

SO-101

Source the parts

Install LeRobot

Step-by-Step Assembly Instructions

Clean Parts

Joint 1

Joint 2

Joint 3

Joint 4

Joint 5

Gripper / Handle

Configure the motors

1. Find the USB ports associated with each arm

2. Set the motors ids and baudrates

Setup motors video

Follower

Leader

LeRobot

Search documentation Ctrl+K

MAIN EN 16,246

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

SO-101

SO-100

Koch v1.1

LeKiwi

RESOURCES

Notebooks

ABOUT

Contribute to LeRobot

Backward compatibility

Example output:

```
Finding all available ports for the MotorBus.
['/dev/tty.usbmodem575E0032081', '/dev/tty.usbmodem575E0031751']
Remove the USB cable from your MotorsBus and press Enter when done.

[...Disconnect corresponding leader or follower arm and press Enter...]
```

```
The port of this MotorsBus is /dev/tty.usbmodem575E0032081
Reconnect the USB cable.
```

Where the found port is: /dev/tty.usbmodem575E0032081 corresponding to your leader or follower arm.

2. Set the motors ids and baudrates

Each motor is identified by a unique id on the bus. When brand new, motors usually come with a default id of 1. For the communication to work properly between the motors and the controller, we first need to set a unique, different id to each motor. Additionally, the speed at which data is transmitted on the bus is determined by the baudrate. In order to talk to each other, the controller and all the motors need to be configured with the same baudrate.

To that end, we first need to connect to each motor individually with the controller in order to set these. Since we will write these parameters in the non-volatile section of the motors' internal memory (EEPROM), we'll only need to do this once.

SO-101

Source the parts

Install LeRobot

Step-by-Step Assembly Instructions

Clean Parts

Joint 1

Joint 2

Joint 3

Joint 4

Joint 5

Gripper / Handle

Configure the motors

1. Find the USB ports associated with each arm

2. Set the motors ids and baudrates

Setup motors video

Follower

Leader

LeRobot

Search documentation Ctrl+K

MAIN EN 16,246

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

SO-101

SO-100

Koch v1.1

LeKiwi

RESOURCES

Notebooks

ABOUT


Contribute to LeRobot

Backward compatibility

If you are repurposing motors from another robot, you will probably also need to perform this step as the ids and baudrate likely won't match.

The video below shows the sequence of steps for setting the motor ids.

Setup motors video



0:00 1:18

Follower

Connect the usb cable from your computer and the power supply to the follower arm's controller board. Then,

SO-101

- Source the parts
- Install LeRobot
- Step-by-Step Assembly Instructions
- Clean Parts
- Joint 1
- Joint 2
- Joint 3
- Joint 4
- Joint 5
- Gripper / Handle
- Configure the motors
  - 1. Find the USB ports associated with each arm
  - 2. Set the motors ids and baudrates
- Setup motors video
- Follower
- Leader

LeRobot

Search documentation Ctrl+K

MAIN EN 16,246

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

SO-101

SO-100

Koch v1.1

LeKiwi

RESOURCES

Notebooks

ABOUT

Contribute to LeRobot

Backward compatibility

Leader

Do the same steps for the leader arm.

Command API example

```
python -m lerobot.setup_motors \
  --teleop.type=so101_leader \
  --teleop.port=/dev/tty.usbmodem575E0031751 # <- paste here the port found at previous
```

Calibrate

Next, you'll need to calibrate your robot to ensure that the leader and follower arms have the same position values when they are in the same physical position. The calibration process is very important because it allows a neural network trained on one robot to work on another.

Follower

Run the following command or API example to calibrate the follower arm:

Command API example

```
python -m lerobot.calibrate \
  --robot.type=so101_follower \
  --robot.port=/dev/tty.usbmodem58768431551 \ # <- The port of your robot
  --robot.id=my_awesome_follower_arm # <- Give the robot a unique name
```

SO-101

- Source the parts
- Install LeRobot
- Step-by-Step Assembly Instructions
- Clean Parts
- Joint 1
- Joint 2
- Joint 3
- Joint 4
- Joint 5
- Gripper / Handle
- Configure the motors
  - 1. Find the USB ports associated with each arm
  - 2. Set the motors ids and baudrates
- Setup motors video
- Follower
- Leader



# Lerobot Configuration



01 Conda installation

02 Lerobot installation/pip install .

03 User interface arrangement  
(ffmpeg, rerun sdk)

04 Login to wandb

05 Install smolVLA (optional)

A screenshot of the LeRobot documentation page on HuggingFace. The page has a dark blue header with the LeRobot logo and a search bar. The main content area is white with a large orange banner featuring the LeRobot logo and a cartoon robot. Below the banner, there's a section titled "LeRobot" with a subtitle "State-of-the-art machine learning for real-world robotics". The page also includes a sidebar with navigation links for "GET STARTED", "TUTORIALS", "POLICIES", and "ROBOTS".

LeRobot

Search documentation

MAIN EN 16,246

GET STARTED

LeRobot

Installation

TUTORIALS

Imitation Learning for Robots

Imitation Learning in Sim

Cameras

Bring Your Own Hardware

Train a Robot with RL

Train RL in Simulation

Use Async Inference

POLICIES

Finetune SmolVLA

ROBOTS

https://huggingface.co/docs/lerobot/ll\_rob

LeRobot

State-of-the-art machine learning for real-world robotics

LeRobot aims to provide models, datasets, and tools for real-world robotics in PyTorch. The goal is to lower the barrier for entry to robotics so that everyone can contribute and benefit from sharing datasets and pretrained models.

LeRobot contains state-of-the-art approaches that have been shown to transfer to the real-world with a focus on imitation learning and reinforcement learning.

LeRobot

Search documentation

MAIN EN 16,246

GET STARTED

LeRobot

Installation

TUTORIALS

Imitation Learning for Robots

Imitation Learning in Sim

Cameras

Bring Your Own Hardware

Train a Robot with RL

Train RL in Simulation

Use Async Inference

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

## Install LeRobot

Currently only available from source.

Download our source code:

```
git clone https://github.com/huggingface/lerobot.git
cd lerobot
```

Create a virtual environment with Python 3.10, using [Miniconda](#)

```
conda create -y -n lerobot python=3.10
```

Then activate your conda environment, you have to do this each time you open a shell to use lerobot:

```
conda activate lerobot
```

When using [miniconda](#), install [ffmpeg](#) in your environment:

```
conda install ffmpeg -c conda-forge
```

Installation

- Install LeRobot
- Troubleshooting
- Optional dependencies
- Simulations
- Motor Control
- Experiment Tracking

LeRobot

Search documentation

MAIN EN 16,246

GET STARTED

LeRobot

Installation

TUTORIALS

Imitation Learning for Robots

Imitation Learning in Sim

Cameras

Bring Your Own Hardware

Train a Robot with RL

Train RL in Simulation

Use Async Inference

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

Install environment packages: [aloha](#) ([gym-aloha](#)), [xarm](#) ([gym-xarm](#)), or [pushit](#) ([gym-pushit](#)) Example:

```
pip install -e ".[aloha]" # or "[xarm]" for example
```

## Motor Control

For Koch v1.1 install the Dynamixel SDK, for SO100/SO101/Moss install the Feetech SDK.

```
pip install -e ".[feetech]" # or "[dynamixel]" for example
```

## Experiment Tracking


To use [Weights and Biases](#) for experiment tracking, log in with

```
wandb login
```


⇒ [Update on GitHub](#)

LeRobot

Imitation Learning for Robots



## Section 3: Experiment setup and dataset collection process





## Data Collection - Core Task

- Collect episodes using the leader arm.
- We collect 75 episodes. Each episode is 25 seconds long
- Prompt: "Wipe red sauce from the plate using sponge."
- Create lot of examples with obstructions for generalization
- Tip: Calibrate robot arm carefully
- Tip: Easier to control with left arm
- Prepared using [phosphobot](#)
- [Dataset Link](#)




## Data Collection - Distributed Samples



## Section 4: Model fine-tuning workflow

### SmolVLA fine-tuning

- 400-500 mB VRAM space needed
- Used default settings (LORA adapter, frozen VLM)
- Worked at commercial laptop with RTX4060
- Took 3-4 hours for 25 samples
- Checkpoints are saved in each 5000 steps
- Total of 20000 steps are trained





Browser tabs: Vision Language Action, SO-101, Installation, Post-Training Isaac GR00, Finetune SmoVLA, StreamYard - Studio

URL: <https://huggingface.co/docs/lerobot/smolvla>

Hugging Face logo | Search models, datasets, users... | Models | Datasets | Spaces | Community | Docs | Pricing | Log In | Sign Up

**LeRobot** | Search documentation | 16,246

MAIN | EN | 16,246

**GET STARTED**

- LeRobot
- Installation

**TUTORIALS**

- Imitation Learning for Robots
- Imitation Learning in Sim
- Cameras
- Bring Your Own Hardware
- Train a Robot with RL
- Train RL in Simulation
- Use Async Inference

**POLICIES**

- Finetune SmoVLA

## Join the Hugging Face community

and get access to the augmented documentation experience

- Collaborate on models, datasets and Spaces
- Faster examples with accelerated inference
- Switch between documentation themes

[Sign Up](#) to get started

## Finetune SmoVLA

SmoVLA is Hugging Face's lightweight foundation model for robotics. Designed for easy fine-tuning on LeRobot datasets, it helps accelerate your development!

### Finetune SmoVLA

- Set Up Your Environment
- Collect a dataset
- Finetune SmoVLA on your data
- Evaluate the finetuned model and run it in real-time

Browser tabs: Vision Language Action, SO-101, Installation, Post-Training Isaac GR00, Finetune SmoVLA, StreamYard - Studio

URL: <https://huggingface.co/docs/lerobot/smolvla>

**LeRobot** | Search documentation | 16,246

MAIN | EN | 16,246

**GET STARTED**

- LeRobot
- Installation

**TUTORIALS**

- Imitation Learning for Robots
- Imitation Learning in Sim
- Cameras
- Bring Your Own Hardware
- Train a Robot with RL
- Train RL in Simulation
- Use Async Inference

**POLICIES**

- Finetune SmoVLA

**ROBOTS**

- Hope Jr

*Figure 1. SmoVLA takes as input (i) multiple cameras views, (ii) the robot's current sensorimotor state, and (iii) a natural language instruction, encoded into contextual features used to condition the action expert when generating an action chunk.*

## Set Up Your Environment

1. Install LeRobot by following our [Installation Guide](#).
2. Install SmoVLA dependencies by running:

```
pip install -e ".[smolvla]"
```

## Collect a dataset

SmoVLA is a base model, so fine-tuning on your own data is required for optimal performance in your setup. We recommend recording ~50 episodes of your task as a starting point. Follow our guide to get started: [Recording a Dataset](#)

In your dataset, make sure to have enough demonstrations per each variation (e.g. the cube position on the table if it is cube pick-place task) you are introducing.

We recommend checking out the dataset linked below for reference that was used in the [SmoVLA paper](#):

[SmoVLA SD100 PickPlace](#)

In this dataset, we recorded 50 episodes across 5 distinct cube positions. For each position, we collected

### Finetune SmoVLA

- Set Up Your Environment
- Collect a dataset
- Finetune SmoVLA on your data
- Evaluate the finetuned model and run it in real-time

LeRobot

Search documentation

16,246

GET STARTED

LeRobot

Installation

TUTORIALS

Imitation Learning for Robots

Imitation Learning in Sim

Cameras

Bring Your Own Hardware

Train a Robot with RL

Train RL in Simulation

Use Async Inference

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

2. Install SmolVLA dependencies by running:

```
pip install -e ".[smolvla]"
```

Collect a dataset

SmolVLA is a base model, so fine-tuning on your own data is required for optimal performance in your setup. We recommend recording ~50 episodes of your task as a starting point. Follow our guide to get started: [Recording a Dataset](#)

In your dataset, make sure to have enough demonstrations per each variation (e.g. the cube position on the table if it is cube pick-place task) you are introducing.

We recommend checking out the dataset linked below for reference that was used in the [SmolVLA paper](#): [SVLA SD100 PickPlace](#)

In this dataset, we recorded 50 episodes across 5 distinct cube positions. For each position, we collected 10 episodes of pick-and-place interactions. This structure, repeating each variation several times, helped the model generalize better. We tried similar dataset with 25 episodes, and it was not enough leading to a bad performance. So, the data quality and quantity is definitely a key. After you have your dataset available on the Hub, you are good to go to use our finetuning script to adapt SmolVLA to your application.

Finetune SmolVLA on your data

Finetune SmolVLA

Set Up Your Environment

Collect a dataset

Finetune SmolVLA on your data

Evaluate the finetuned model and run it in real-time

LeRobot

Search documentation

16,246

GET STARTED

LeRobot

Installation

TUTORIALS

Imitation Learning for Robots

Imitation Learning in Sim

Cameras

Bring Your Own Hardware

Train a Robot with RL

Train RL in Simulation

Use Async Inference

POLICIES

Finetune SmolVLA

ROBOTS

Hope Jr

Use [smolvla\\_base](#), our pretrained 450M model, and fine-tune it on your data. Training the model for 20k steps will roughly take ~4 hrs on a single A100 GPU. You should tune the number of steps based on performance and your use-case.

If you don't have a gpu device, you can train using our notebook on [Open in Colab](#)

Pass your dataset to the training script using `--dataset.repo_id`. If you want to test your installation, run the following command where we use one of the datasets we collected for the [SmolVLA Paper](#).

```
cd lerobot && python -m lerobot.scripts.train \
  --policy.path=lerobot/smolvla_base \
  --dataset.repo_id=${HF_USER}/mydataset \
  --batch_size=64 \
  --steps=20000 \
  --output_dir=outputs/train/my_smolvla \
  --job_name=my_smolvla_training \
  --policy.device=cuda \
  --wandb.enable=true
```

You can start with a small batch size and increase it incrementally, if the GPU allows it, as long as loading times remain short.

Fine-tuning is an art. For a complete overview of the options for finetuning, run


Finetune SmolVLA

Set Up Your Environment

Collect a dataset

Finetune SmolVLA on your data


Evaluate the finetuned model and run it in real-time



## GR00T-N1.5 Model Fine Tuning


- ~20GB VRAM needed!
- Ori provided free credits to train the model in their clusters
- Took 1 hour with H100 GPU
- Used default settings, LORA adapter
- Used new embodiment setting
- Model trained on 20000 steps
- Checkpoints are saved in each 1000 step

1 skill for less than 3 dollars









## Section 5: Running inference on the real robot

### GR00T-N1.5 Model Inference and Model Evaluation

- 01 Give cloud computers access to the local ports
- 02 Run the inference with the latest checkpoint
- 03 Test different prompts
- 04 Test the generalization prompts
- 05 Evaluate the success rate

### Cloud-Based GR00T Inference with 16-Action Window

#### Setup

- Inference Location: Ori Cloud H100 GPU (GR00T model)
- Action Window: 16 predicted actions per inference
- Cloud inference adds ~300–500 ms latency
- 16-step prediction reduces stop-and-wait behavior
- Allows robot to move continuously between cloud updates

## Inference for the core task



Wrist joint camera view



Real-time performance of GR00T-N1.5  
deployed on SO101 follower

## Model's generalization ability



New Plate



More Sauce



More Spoons

## Struggles of Spice Terminator



Unable to grasp

## Async vs Sync Inference (Le Robot + GR00T)

### Synchronous

Stop → Think → Act

Robot waits for GR00T prediction before moving

✓ Stable & deterministic

✗ Slow, high latency → jerky if cloud-based


### Asynchronous

Keep moving while inference runs in background

✓ Smoother, lower perceived latency

✗ Can act on stale observations, harder to 'debug'

SO-101 Arm Cloud Setup



## Section 6: Web UI Integration

